

8028 configure with an OnSIP SIP server

Get extension information from OnSIP

To start the process, you will need the following information:

Address of Record: YYYYYYY@desertfuels.onsip.com

SIP Password: 0000000000000

Auth Username: xxxxxxxxxxxx

Username: YYYYYYY

Proxy/Domain: xxxxxx.onsip.com

Proxy/Domain IP address of xxxxxx.onsip.com: 1111.2222.3333.4444

To find the Proxy/Domain IP address of xxxxxx.onsip.com open a Command Prompt on a Windows computer connected to Internet and write “ping xxxxxx.onsip.com” and click enter.

Configure the Algo 8028

- 1) SIP Domain/Proxy = Proxy/Domain = xxxxxx.onsip.com
- 2) Outbound Proxy (optional) = Proxy/Domain IP address = 1111.2222.3333.4444
- 3) Extension = Username = YYYYYYY
- 4) Auth ID = Auth Username = xxxxxxxxxxxx
- 5) Password = SIP Password = 0000000000000
- 6) Dialing Extension = Extension to dial when the door station button is pushed.
- 7) Select “Double CRLF” under Keep-alive Method if your device is behind a NAT firewall.

SIP	
<input type="checkbox"/> SIP Domain/Proxy	xxxxxxx.onsip.com
Outbound Proxy (optional)	1111.2222.3333.4444
STUN Server (optional) ⓘ	
Registrar (optional)	
Register Period (seconds)	3600
Keep-alive Method	<input type="radio"/> None <input checked="" type="radio"/> Double CRLF
Keep-alive Period (seconds)	30
<input type="checkbox"/> Extension	YYYYYYY
Auth ID	xxxxxxxxxxx
Password	●●●●●●●●●●●●●●●●
Dialing Extension	0000