

sipXecs

Configure SIP extension on sipXecs

In the Home web page click on Users -> Users.

The screenshot shows the sipXecs web interface. The header includes the sipXecs logo and navigation links for Home and Help. The main navigation bar has tabs for Users, Devices, Features, System, and Diagnostics. The 'Users' tab is active, displaying a table of users. A 'Filter by...' dropdown menu is located above the table. The table has columns for User ID, First Name, Last Name, and Aliases. The 'Add User' link is visible on the right side of the page.

<input type="checkbox"/>	User ID ▼	First Name	Last Name	Aliases
<input type="checkbox"/>	1107	Test2	IPMI	
<input type="checkbox"/>	1110	No5Ring	David	
<input type="checkbox"/>	1111	No5Page	David	
<input type="checkbox"/>	1201			
<input type="checkbox"/>	1202			

On the right, click on “Add User”.

- 1) “User ID” is the extension that will be used.
- 2) Enter a default “PIN”: 0000
- 3) Keep the “SIP password” or change it. The SIP password is needed to configure the 8180 SIP extension.
- 4) Click OK.

The extension is now ready to be used.

New User

User ID

The User ID can be a numeric extension name of the user. If using Direct In

Last name

First name

Active greeting

Voicemail prompt callers will hear b

E-mail address

Used for sending notification about

Attach voicemail

If checked, the voicemail message

Additional E-mail address

Used for sending voicemail messag

Attach voicemail

If checked, the voicemail message

PIN

Confirm PIN

The PIN is a password used to log

SIP password

The SIP password is used by the u: phone. For unmanaged phones, the password is auto-generated.

Groups

List all groups for this user. If a gro

Aliases

Aliases are additional names for th

Create another user after this one?

OK

Apply

Cancel