


Announcing a Doorphone Visitor Call (Visual Alerting)

The Norstar/BST Doorphone can be programmed to provide page chimes and/or to ring telephones when its call button has been pressed. Sometimes, however, it may be desirable to announce that a visitor has arrived with a quiet visual indication. Typical scenarios include recording studios, nurseries, or facilities for the hearing impaired.

The optional Door Opening Controller (available from Nortel Networks) is capable of providing a dry-contact closure whenever the call button of the Norstar/BST Doorphone is pressed. These contacts can be used to activate the 1127P Desktop Visual Alerter.

In the diagram at right, power supply connections are omitted for clarity. The Door Opening Controller requires a separate power supply that has not been added to the requirements section, due to the fact that the power supply included with the 1127P Desktop Visual Alerter can provide power for the Door Opening Controller as well. For a brighter visual notification, the 1126P Strobe Light can be used in place of the 1127P.

For Norstar / BST Doorphones



Requirements

- BST Doorphone A0518264 (Or Norstar Doorphone from Nortel Networks)
- Door Opening Controller AO618971
- 1127P Desktop Visual Alerter or 1126P Strobe Light
- Pre-wire