

## 1081 Message Waiting Module Installation Guide

### GENERAL:

The Message Waiting Module is intended for use with a Station Port message waiting signal and a DUET PLUS with an attached Strobe Light to provide flashes from the Strobe light in response to ringing or message waiting.

### INSTALLATION:

- (1) Connect the Green lead of the Message Waiting Module to the Tip and the Red lead to the Ring of the Station Port.
- (2) Connect the 2 White wires to the 10 VAC terminals of the Duet Plus.
- (3) Connect a Strobe Light to the AUX SPKR terminals of the Duet Plus.
- (4) Adjust the volume control of Duet Plus to maximum.

